

## 1543650 - Couvercle gobelet 4 mm - transparent - 1 pc



### Spécifications

**A utiliser avec:**

Beker (1543655, 1543659, 1543660, 153661, 1543639, 1543638, 1543671, 1543637, 1543662, 1543642, 1543673, 1543663, 1543643, 1543674, 1543664, 1543644, 1543665, 1543645, 1543646, 1543666, 1543667)

<b>Composition</b>	Polypropylène
<b>Couleur</b>	Transparent
<b>Ouverture couvercle gobelet</b>	4 mm
<b>Réglementation Européenne</b>	MDD - 93/42/EEC - Classe I
<b>Type d'emballage</b>	Pièce